

** When printing this pattern, please print it without any margins at actual size.


** After printing the pattern and taping the pieces together, please follow the reference the provided size guide (3" or 5").

** If the pattern fits inside a single page of letter and/or A4 paper then taping is not required.

** Patterns marked as A4 are for users who utilize the A4 standard paper size.

** Patterns marked as A4 are for users who utilize the A4 standard paper size. If the pattern fits inside a single page of letter and/or A4 paper then a separate A4 size file is not included, as the pattern will work with both paper sizes



** If you experience that certain parts of the pattern are not printing, you should be able to ignore those near the edge/border. These are usually just guides & signs.



Place on Fold: This means to draw the pattern on the other side as well by folding the fabric to the line. Therefore making two times the original pattern.

 CUTTING LINE

© 2020 Copyright of ithinksew.com
Personal use only.



3"(7.62cm)